



WL-USB-200 INSTALLATION INSTRUCTIONS

DISABLE YOUR INTERNAL WIRELESS WHEN USING THIS ADAPTER

In order to avoid conflicts and achieve the best performance, you must disable your laptop's built-in wireless whenever you use the WiFi to USB adapter. Some laptops have a wireless switch or button which allows you to easily disable your internal wireless capability. If your laptop does not have such a switch, use the software that came with your computer to turn off or disable your built-in wireless.

Windows Vista

1. Insert the CD into your computer
2. Insert the WiFi to USB Adapter into a USB port.
3. The New Hardware Wizard will appear
4. Select "Locate and install Driver" and follow the prompts
5. The WiFi to USB driver is now installed and ready to use.

Windows XP

1. Insert the CD into your computer
2. Insert the WiFi to USB Adapter into a USB port.
3. The New Hardware Wizard will appear
4. When asked to connect to Windows Update, select "No, not this time".
5. Select "Install the software automatically (Recommended)"
6. The New Hardware Wizard will suggest a driver, click "Next".
7. The WiFi to USB driver is now installed and ready to use.

Windows 98/ME/2000

1. Insert the CD into your computer
2. Run the Setup program on the CD and follow the installation prompts
3. Insert the WiFi to USB Adapter into a USB port.

Mac OSX

1. Note that you must be running OSX 10.4 or higher.
2. Insert the CD into your Mac
3. Insert the USB Adapter into a USB port.
4. Browse the CD and select the Driver Folder
5. Select the "RTL8187B_MacOS10.4_Driver_1117_UI_1.5.1A" folder.
6. Click on "Install.mpkg" to install the utility.
7. Your MAC may ask to restart.
8. After restarting, look in the Applications menu for "Realtek Utility".
9. Use the Realtek Utility to connect to wireless networks.